
2115QXPA Air Impactool™ - Exploded View









2115QXPA Air Impactool™ - Parts List

Item	Part Description	Part Number	(CCN)	Item	Part Description	Part Number	(CCN)
	Housing Assembly	2115QXPA-A40	(2115QXPA-A40)		Reverse Valve Assembly	2131-A329	(04167896)
1	Housing			25	Reverse Valve		
3	Warning Label			25A	O-Ring, Reverse Valve (Top-Black)		
4	Information Label						
24	Gasket, Motor			25B	O-Ring, Reverse Valve		
	Reverse Valve Assembly				(Bottom-Blue)		
	(includes 25, 25A, 25B)				Inlet Bushing Assembly	2135-D565A	(45531787)
29	Button Kit			26	Inlet Bushing		
2	Screw, Hammer Case	mer Case 2115-638	(80126170)	27	Inlet Clip	2131-57	(04167862)
	(4 required)			28	Inlet Parts Kit	2135-K303	(45535051)
3	Warning Label	WARNING-2-99	(04203139)	28A	Washer		
4	Information Label	2115QXPA-300		28B	O-Ring, Seal		
	Power Regulator Assembly	2115-D249A	(45561735)	28C	Throttle Spring		
5	Power Regulator		(+3301733)	28D	Throttle Valve		
5A	O-Ring, Power Regulator			28E	Valve Seat		
6	Retaining Ring	4E-6	(03079530)	28F	Seat Support		
7	Ball Bearing (Cylinder)	R00H-97	(03100021)	28G	Retainer		
8	Cylinder	2112-3	(04679056)	29	Button Kit	2115-K75RD	(45583465)
9	Rotor	2115-53	(45504990)	29A	Forward Button		
†10	Vane Pack (set of 7)	2115-33 2115-42A-7	(45583473)	29B	Reverse Button		
11	End Plate	2112-11	(04679064)	30	Silencer	2115Q-311	(45587342)
12	Ball Bearing (End Plate)	2131-97	(04679064)	*	Tune-Up Kit	2115-TK2	(45585189)
†13	Hammer Case Gasket	2115-36	(45550779)	5A	O-Ring, Power Regulator		
	Hammer Mechanism Kit	2115-30 2115-THK2	(45585932)				
14	Hammer (2)	2113-1HK2	(45565952)	6	Retaining Ring		
15	Hammer Frame			7	Ball Bearing (Cylinder)		
15A	Hammer Pin (2)			10	Vane Pack (set of 7)		
ISA	Anvil Assembly	2112-A626	(10319895)	12	Ball Bearing (End Plate)		
16	Anvil	2112-A020	(10319693)	13	Hammer Case Gasket		
17	O-Ring			23A	O-Ring, Trigger		
18	Socket Retainer			24	Gasket, Motor		
†	Socket Retainer Kit	2115-K425	(80107659)	25A	O-Ring, Reverse Valve		
17	O-Ring	2113-1423	(80107039)	23/1	(Top-Black)		
18	Socket Retainer			25B	O-Ring, Reverse Valve		
19	Bushing, Hammer Case	2112-641	(04679114)	230	(Bottom-Blue)		
17	Hammer Case Assembly	2115AL-D727A	(45586443)	28	Inlet Parts Kit		
10		1		*	Kit, Piped-Away Exhaust	2115-K284	(45612637)
19	Bushing, Hammer Case			*	Inlet Clip Removal Tool	2131-322	(04263745)
20	Sleeve, Hammer Case			+*	Air Care Kit	115-LBK1	(04616108)
21	Hammer Case			1*	(grease gun, grease, oil)	I I J-LDN I	(04010106)
22	Grease Fitting			*	Grease	115-4T	(04616157)
22	Grease Fitting	130SR-188	(03039930)		(replacement tube for -LBK1)		
	Trigger Assembly	2135-D93	(80096704)	*	Air Tool Oil (4 oz. bottle)	10Z4	(03875671)
23	Trigger			*	Grease (1 lb can)	105-1LB	(04279147)
23A	O-Ring, Trigger			*	Grease (8 lb can)	105-8LB	(04264875)
†24	Gasket, Motor	2112-283	(04679015)	*	Grease Gun	R000A2-228	(03095015)

^{*} Indicates not illustrated.

Parts and Maintenance

When tool life has expired, it is recommended that the tool be disassembled, degreased and parts separated by material for proper recycling.

 $Tool\ repair\ and\ maintenance\ should\ only\ be\ carried\ out\ by\ an\ authorized\ Service\ Center.$

Refer all communications to the nearest $\boldsymbol{\textbf{Ingersoll Rand}}$ office or distributor.

Related Documentation

Manuals can be downloaded from ingersollrandproducts.com

For additional information, refer to: Product Safety Information Manual 04580916. Product Information Manual 47598152001. Declaration of Conformity 47626564001.



[†] Indicates common-wear parts. Maintain stock to reduce downtime.